

INDEX

**Discontinued Fuel Injection Service Manual
Index & Check List**

The information on the following 35 microfiche cards are all parts lists and calibrations specifications from the Discontinued Fuel Injection Service Manual.

Previously, a hard copy of this material was furnished to each new central distributor, service distributor and service station upon signing on with AMBAC International. We've found this to be cumbersome and costly. Therefore, all data was converted in its original format to microfiche.

This microfiche section will not be updated nor will you be given additional copies. Please file this material to insure that it will not be lost or destroyed as no replacement will be given.

This index uses the same section numbers as the discontinued manual and also shows on which card you will find the information you are seeking.

<u>Description</u>	<u>Section #</u>	<u>Card #</u>
APE		
APE 1A	D100	1
APE 1B	D103, D105	1
APE 1Z	D106	1
APE 2A	D108	1
APE 2B	D112, D113	1
APE 3A	D115	1
	D117	2
APE 3B	D122, D123	2
APE 4A	D120	2
	D127, D129	3
APE 4B	D125, D131, D132, D133/50	4
	D133/300	5
APE 4BB	D133/1500	5
APE 4Z	D135	5
APE 6A	D135/160	5
	D135/160v pp. 1-45	5
	D135/160v pp. 46-89	6
	D139 - D139/51	6
	D139/900 - D139/1057	7
	D139/1057A - D140	8
APE 6B	D141 - D142/45	8
	D143 - D143/104	9
APE 6B..Q & ..QK	D140/120 - D140/120v	9
	D140/121 - D143/736	10
APE 6BB..Q	D143/1500 - D143/1576 pp. 1-23	11
	D143/1576(pp. 25-30) - D145/126	12
APE 6Z	D144 - D145/10	13
APE 8B..Q	D155/120 - D160/120v	13
APE 8VBB	D165/121 - D161/121v	13

<u>APF</u>		
APF 1A	D175/100 - D176/1	14
APF 1B	D180/100 - D182/7	14
APF 1BC	D183/100 - D183/100v	14
APF 1C	D185/100 - D192/101	14
APF 1CC	D190/100 - D190/102v	15
APF 1CD	D192/300 - D192/301	15
APF 1CG	D191/100	15
APF 1CQ	D195/100 - D195/101v	15
APF 1D	D197 - D200/100v pp. 1-24	15
	D200/100v pp. 25-28	16
APF 1DD	D205/100 - D205/100v	16
APF 1E	D206/1-8	16
APF 1F	D206/100 - 101	16
PLB 1A	D216	16
PUB 1A	D218	16
PUB 1B	D219	16
<u>PSB</u>		
PSB A 6 & 4	D220/145 - D220/170v	17
PSB A 4	D226/350 - D226/521	17
	D226/522 - D226/869	18
	D226/870 - D226/1100-7	19
PSB 6	D226/1400 - D226/1822	20
	D226/1850 - D226/1912	21
	D226/2000 pp. 1-26	22
<u>PSJ</u>		
PSJ 6A	D230/1000 - D230/2036	23
	D230/4000 - D230/4051 pp.1-9	24
	D230/4051-1 - D230/4052 pp.1-6	25
<u>PSM</u>		
PSM 6A...D	D231/100 - D231/102-1	26
PSM 6A...E	D231/110 pp. 1-24	26
	D231/110 pp. 25-31 - D231/112	27
<u>PSU</u>		
Hydraulic Heads	D235/110 - D235/122 pp. 1-3	27
Supply Pumps,	D240/1 - D240/5002	28
Manual Primers,	D260/1000 - D280/3201	29
Overflow Valves,	D1902 - D1902/2, D100/100	29
Timing Devices,		
Manual Couplings		
Service Instructions		
Governors, Pneumatic	D290 - D321/2	30
GVA.../...A	D322	30
GVA.../...B	D323	30
GVA.../...BK	D324	30
GVA.../...PK	D325/100	30
	D325/100v	31

GVB.../...A	D327	31
GVB.../...BK	D330	32
GVB.../...C	D330/110 - D330/311	32
GVB.../...D	D330/520 - D330/900	32
GVB.../...PK	D335/100 - D335/100V	33
Conversion Kits	D340, IF 7925, 7926, 7928, 7929	33
	D352	33
Nozzle Holders	D380/310 - D390/5000	34
AKB...R	D400	34
AKB...S	D500 - D500/2	34
AKB...T	D600 - D600/5	35
AKB...U	D700 - D700/3	35
AKB...V	D800	35
AKC...S & SD	D900	35
AKD	D900/120	35
AKF	D907 - D908/1	35
AKK	D910 - D940	35
AKL - AKS	D950/101 - D1200/490	35