

GVB

B

Illustration No.

Description of Part

- 92 WASHER, plain—end cover screw
- 94 GASKET, end cover screw
- 95 SCREW, end cover fastening
- 96 SCREW, housing mounting
- 97 PLUG, housing mounting
- 98 SCREW, Bowden wire fastening
- 99 SCREW, clamping
- 100 LEVER, shutoff
- 101 NUT, clamping screw
- 102 PIN, cotter—clamping screw
- 103 WASHER, plain
- 104 SEAL, oil
- 105 PIN, cotter
- 106 SHAFT, stop lever
- 107 BUSHING
- 108 SPACER
- 109 SCREW, inner stop lever
- 110 LEVER, inner stop
- 111 SPRING, stop lever
- 112 BUSHING
- 113 WASHER, snap ring retaining
- 114 RING, snap
- 115 PLUG, closing
- 116 SCREW, bracket fastening
- 117 WASHER, lock
- 118 SCREW, clamping—Bowden wire
- 119 BRACKET, Bowden wire
- 120 NUT, clamping screw



